



PINK PROFESSIONAL TRIPLE ROLL-ON WAX HEATER



EN Instructions Manual

PINK PROFESSIONAL TRIPLE ROLL-ON WAX HEATER

INTRODUCTION

The PINK Professional Triple Roll-on Wax Heater is a professional heating appliance, ideal for heating all types of non-coded 80 and 100 ml wax and sugar cartridges. We have paid particular attention to the safety of our appliance, which complies with all relevant European standards.

CAUTION: This appliance can be heated to very high temperatures. In order to prevent injury, please read these instructions carefully before using the appliance for the first time.

HIGHLIGHTS

- Heating chambers for up to three cartridges
- Fast heat up time
- Plastic clamp for safe & easy use
- Easy-to-operate temperature dial on the side of the appliance
- Easy to clean

SAFETY GUIDELINES

- Never leave the heater switched on when empty
- Never leave the heater switched on overnight
- When hot, do not touch the cartridge or the heating chamber (risk of burns!)
- Keep out of reach of children
- If the appliance malfunctions during the heating process, unplug immediately, and contact PINK Cosmetics GmbH
- Never open the appliance yourself - risk of electric shocks. Only authorised technical personnel from PINK Cosmetics GmbH may access the parts inside the appliance. For repairs or further information, you must contact PINK Cosmetics GmbH.
- Never use the heater if the plug or power cable are damaged, if you notice the appliance is not functioning properly, if the appliance was dropped and/or damaged, or if the appliance has come into contact with water
- Always allow the appliance to cool down completely before storing

INSTALLATION

Open the top of the box and remove the appliance. It is recommended that you keep the original packaging in case you need to return the appliance in the future. The installation site should have a smooth, flat, solid surface. Direct sunlight and exposure to a dusty environment must be avoided. The mains power supply must comply with legal requirements and be suitable for the appliance.

CAUTION: Do not use the appliance near water or in damp areas.

INSTRUCTIONS FOR USE

1. Insert cartridge into the heating chamber and close the lid.
2. Set device to level 6 (for StripAway Roll-on Strip Wax). The working temperature is reached after approx. 20 minutes (depending on the room temperature and the quantity of wax).
3. At the right temperature, the wax has a thin, honey-like consistency and moves easily back and forth inside the cartridge.


4. For safe any easy use, clip the plastic clamp onto the cartridge.
5. Directly after each application, put the cartridge back inside the heater.

Please note: The settings and times given are approximate values which may vary depending on the room temperature, the consistency of the depilatory product, and the fullness of the cartridge

CLEANING

After use, clean the heating appliance with a special cleaner/wax remover e.g. PINK Wax Solvent. Wax residues are easy to remove from the surface of the heater while the appliance is still warm. Make sure you have unplugged the appliance before cleaning. PLEASE NOTE: Use only cleaning products designed to remove wax.

TECHNICAL SPECIFICATIONS

- 220 – 240 V, 50 Hz
- 130 watt
- Maximum temperature: 90 °C
- Capacity: 3x 80/100 ml cartridges
- This heating appliance conforms to the following directives:
 - Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS) 2011/65/EU - Delegated Directive (EU) 2015/863
- The appliance is CE certified and bears the CE mark
- The symbol  indicates that disposal of this device must be in accordance with the local regulations

WARRANTY

The manufacturer's warranty is valid for 12 months from the date of purchase under the following conditions:

- A dated sales receipt and contact details must be provided for any repair covered by the warranty
- Damage due to the following is not covered by the warranty:
 - Plugging the appliance into the wrong electricity voltage or the wrong type of current
 - Dropping the appliance, negligence, disassembly, improper use (see also the section entitled "Safety guidelines")
 - Repairs or alterations carried out by a non-certified electrical company
- If the serial number is damaged, altered, or removed, all warranties are invalid
- The warranty does not cover normal wear and tear

COMPLAINTS

In the event of a complaint, please email our customer service at: service@pink-cosmetics.com



PINK Professional Wax Heaters



**PINK PROFESSIONAL
SINGLE ROLL-ON WAX HEATER**



**PINK PROFESSIONAL
TRIPLE ROLL-ON WAX HEATER**



**PINK PROFESSIONAL
WAX HEATER 200 ML**



**PINK PROFESSIONAL
WAX HEATER 450 ML**



**PINK PROFESSIONAL
WAX HEATER 800 ML**



**PINK PROFESSIONAL
WAX HEATER 1000 ML**



Waxing at its BEST!



social.pink-cosmetics.com



pink-waxing-academy.de



pink-cosmetics.com



shop.pink-cosmetics.com



+49 211 - 99 33 04 46 1 (International)



0800 - 014 81 79 (Great Britain)



1800 - 85 23 36 (Ireland)

